




**UNIVERSAL MEDIATION  
INTERFACE (UMI) MODULE  
USER'S MANUAL SUPPLEMENT  
FOR BNS/DATAKIT® II VCS NODES**  
Issue 1.2  
(Corresponds to UMI Build 20 or higher)



721 Route 202-206  
Bridgewater, NJ 08807  
fax: 908.218.1736  
phone: 908.218.0500  
email: [sales@datatekcorp.com](mailto:sales@datatekcorp.com)  
<http://www.datatekcorp.com>



## CONTENTS

1	Introduction.....	3
2	Prerequisites and Caveats .....	3
3	Feature Summary .....	4
4	Database Issues.....	4
5	Commands.....	5
5.1	Retrieve and Convert.....	5
5.2	Enter and Change .....	6
5.3	Verify .....	10
5.4	Remove and Restore .....	16
5.5	Delete .....	16
5.6	SAM - Based Commands .....	18
5.6.1	Display Measurements.....	19
5.6.2	Display Status .....	19
5.6.3	Verify Comment .....	19
6	Appendix – Command/Parameter Comparison Table .....	20
7	Hardware Warranty.....	25
8	End-User License Agreement for Software .....	25
8.1	Software License .....	25
8.2	Intellectual Property Rights .....	25
8.3	Software Support.....	26
8.4	Export Restrictions.....	26
8.5	Limited Warranty.....	26
8.6	No Other Warranties.....	26
8.7	Special Provisions.....	26
9	Limitation of Liability.....	27



## 1 INTRODUCTION

Connectivity between an IP network and a BNS (refers to both BNS-2000 and BNS-2000 VCS (aka. Datakit® II VCS)) network is accomplished using the **Universal Mediation Interface Module (UMI)**. As a state-of-the-art “solid state” module that resides in a BNS node, the **UMI** is both a replacement and enhancement of the LCS60 product.

The **UMI** allows both synchronous and asynchronous endpoints connected to a BNS network to access endpoints on an IP network. Similarly, endpoints on an IP network can access both synchronous and asynchronous endpoints on a BNS network.

The **UMI** can be located anywhere in the BNS network, thus simplifying configuration, administration and maintenance without affecting operation or connectivity.

This document is a supplement to the “**Universal Mediation Interface User Manual (UM-UMI)**” and to the standard BNS documents: “**Data Networking Products, Synchronous/Asynchronous Multiplexor Reference**” and “**Data Networking Products, Commands Reference**”. This supplement documents the new feature for a BNS/Datakit controller that allows a **UMI** module to be configured as standard BNS module, namely a **UMI**, in the node. Prior to this feature the **UMI** was configured on the BNS controller as a SAM504, mapping 504 BNS ports to 504 “virtual ports” residing in the IP network. All IP configuration data was entered directly on the **UMI** console. Hence, every virtual port had to be configured twice, once on the node and once on the **UMI** module itself. With this feature, the Base Configuration of the **UMI** and the configuration of all the virtual ports (**vports**) including their IP information is performed on the BNS node only, and downloaded to the **UMI** module when it is restored to service. The major benefits are that all the IP configuration information for the module and all the virtual ports can be entered, changed, verified, saved, and backed-up on the BNS controller, just like for any other BNS module, and once only.

This document provides all the new commands and changes made in the node's controller. A new maintenance release of the node controller software must be obtained and installed on a node in order to use this feature. Presently, this feature is available for nodes running BNS-2000 VCS (Datakit II VCS) Release 6.0 only and soon for BNS-2000 Releases 4.0 and 5.0. Explanation of each of the comparable parameters in the commands is shown in the UM-UMI.

## 2 PREREQUISITES AND CAVEATS

There are a few prerequisites and caveats:

1. It is assumed that the reader is already familiar with the terminology, methods, and conventions in the BNS/Datakit documentation that are used to configure modules in a node, and that a copy of the UM-UMI is available for reference. The format of the commands described below is the same as used in existing BNS documentation.
2. The **UMI** module must have build 19 or above installed in it. Build 20 or above is required for the SNMP CUG, DESTINATION PDD and the multiple DNS IP ADDRESS features.
3. BNS-2000 VCS (aka. Datakit II VCS) Release 6.0 Build 87 or above must be installed on the node.

---

® Datakit is a registered trademark of Lucent Technologies, Inc., licensed to Datatek Applications, Inc., a company independent of Lucent Technologies, Inc.



4. In order for StarKeeper® II NMS to properly recognize and process *UMI* module information, a free patch for Release 10.0, available from Datatek Applications, Inc. must be installed. The patch information and the associated installation instructions are available from the Datatek web site [www.datatekcorp.com](http://www.datatekcorp.com) by clicking on the "Software Download" link.

### 3 FEATURE SUMMARY

For this feature the object *umi* and its associated new components have been added to several controller commands.

The affected commands are:

1. **Enter/Change/Delete/Verify UMI**, with the components **Module, Vport, PDD, Host and CUG**.
2. **Remove/Restore UMI** with components **Module and Vport**.
3. **Retrieve UMI and Convert .... UMI**

For other commands, *sam* is used as the argument even though the actual entity is a *UMI* module. These commands are:

1. **Display Measurements**
2. **Display Status**
3. **Verify Comment**

The syntax and details are described in later sections.

A third set of commands does not use *sam* or *umi* as an argument, but are applicable. Examples of these are:

1. **Verify Oosmods** – this command identifies *UMI* modules in the output
2. **Display Circuits**
3. **Others**

### 4 DATABASE ISSUES

If a *UMI* has been previously configured on the node as a SAM504 and in the *UMI* module itself, the information does not all have to re-entered when using this feature. The Datakit node *retrieve* and *convert* commands can be used. However, if there is an inconsistency between the definition on the node of a SAM port and the information in the *UMI* module, the converted configuration will be consistent with the information originally in the node definition.

The new *UMI* configuration information will be added to the controller disk files in /etc. New files are generated and named *umimod.<mod mo.>*. These files will be included in all of the database management processes including *backup* and *sync*. Therefore, installation of the BNS-2000 VCS, Release 6.0 Build 87 or higher, BNS-2000 Release 4.0 Build 89 or higher, or BNS-2000 Release 5.0 Build 82 or higher does not require a database upgrade or conversion for this feature.

---

® StarKeeper is a registered trademark of Lucent Technologies, Inc., licensed to Datatek Applications, Inc., a company independent of Lucent Technologies, Inc.



After a **UMI** module has been configured on the node using the new controller capability, if a user enters a change via the **UMI**'s console, that change is not saved in the BNS database. Therefore when that module is re-downloaded from the controller as the result of a restore command, all changes entered via a **UMI** console will be lost. All changes should be installed using the BNS edit commands on the node.

## 5 COMMANDS

The commands presented below can be entered either in prompted mode, single line mode, or a combination, just like for other BNS commands. The appendix shows the correspondence between the commands and parameters that were entered at a **UMI** module console and those that are now entered via a BNS-2000 VCS console on a node or a StarKeeper console via the **setnode** command.

For change, verify and delete commands, the values for some parameters can be ranges. If a range specifies all possible values for a parameter, the controller interprets the range as meaning "all configured values". If something less than the entire range is specified, then all entities in that range have to have been previously configured. Otherwise, the command is rejected. For example, in verify umi vport, the user can specify the range 1-504 for the vport number which is interpreted as "all". If only 300 of the possible 504 vports have been configured, the command would execute properly and all 300 vports displayed. However, if the user had specified the range 1-503 in the command and only 300 ports had been configured, the command would be rejected.

It's important to note that although a single **UMI** supports call setup in both directions simultaneously, each grouping of virtual ports must be configured for one direction only; i.e., there are no two-way virtual ports. In addition, virtual ports intended to be used for synchronous and asynchronous call connections must reside in different groups, since their protocol encapsulation is different.

### 5.1 Retrieve and Convert

If an existing definition of the **UMI** exists in the node as a SAM504 and in the **UMI** itself, there are two utilities to assist the administrator to convert these definitions into **UMI** defined on the controller: **Retrieve** and **Convert**.

```
CC0> retrieve umi <mod no.>
```

Where *the module address* is the number of the in-service SAM504 module. The command requests IP configuration information from the **UMI**. The replies from the **UMI** will be used to build a configuration file for the **UMI**. The module must be in service for the control computer to communicate with it.

After the **retrieve** command is run, the module must be converted from a SAM504 to a **UMI**. Remove the module with:

```
CC0> remove sam module <mod_no>
```

With the SAM504 out of service, run the following command which will convert the SAM504 to a **UMI** and add any missing configuration

```
CC0> convert module <mod_no> umi
```



## 5.2 Enter and Change

The prompts below are the same for both the **enter** and the **change** commands. For the **enter** command, the default for a parameter is shown in parenthesis for that parameter when there is a default. For the **change** command, the default value is the currently configured value for that parameter.

```
CC0> enter or change
OBJECT: [...umi...] umi
COMPONENT: [module, vport, cug, host, pdd]
```

**If COMPONENT is “module”:**

*(The parameters correspond to the “local”, “gateway”, “dns” and “snmp” commands on the UMI console.)*

```
MODULE ADDRESS:
COMMENT [up to 60 chars double quoted]:
DOWNLOAD SERVER [(controller)]:
SOFTWARE VERSION [(standard)]:
GATEWAY ADDRESS [decimal dot notation: +(none)]:
LOCAL IP ADDRESS [decimal dot notation: +(none)]:
LOCAL IP SUBMASK [decimal dot notation: +(none)]:
SNMP IP ADDRESS [decimal dot notation | none: +(none)]:
SNMP IP PORT [1-65535 | none: +(none)]:
SNMP IP CUG LIST [1-32 | 0 for none +(0)]:
DNS IP ADDRESS 1[decimal dot notation | none: +(none)]:
DNS IP ADDRESS 2[decimal dot notation | none: +(none)]:
DNS IP ADDRESS 3[decimal dot notation | none: +(none)]:
DOMAIN NAME 1[mnemonic | none: +(none)]:
DOMAIN NAME 2[mnemonic | none: +(none)]:
DOMAIN NAME 3[mnemonic | none: +(none)]:
```

*The command then loops back to the MODULE ADDRESS prompt.*



**Enter and Change - continued**

*If the COMPONENT is "vport":*

*(The following prompts correspond to the parameters in the "vport" command on the UMI console.)*

MODULE ADDRESS:  
VPORT NUMBER [1-504: +(1-504)]:  
COMMENT [up to 60 chars double quoted]:  
PROTOCOL [async, sync, raw]:  
SERVICE TYPE [bns\_to\_ip, ip\_to\_bns: +(ip\_to\_bns)]:  
GROUP [up to 8 chars]:

*If PROTOCOL is "sync" and SERVICE TYPE is "ip\_to\_bns":*

PREDEFINED DESTINATION:

*If PROTOCOL is "async" or "raw" and SERVICE TYPE is "ip\_to\_bns":*

PREDEFINED DESTINATION [+(none)]:  
SESSION HOLD [on, off +(off)]:

*If SESSION HOLD is "on":*

ATTENTION CHARACTER [none, lbrk, del, a character: +(lbrk)]:  
ATTENTION ACTION [command\_mode, disconnect: +(command\_mode)]:

*If PROTOCOL is "async" or "raw" and SERVICE TYPE is "ip\_to\_bns":*

NODE ECHOES USER INPUT [yes, no: +(yes)]:

*If PROTOCOL is "async" or "raw":*

NULL AFTER CARRIAGE RETURN [transparent, no\_null:  
+(transparent)]:  
LF AFTER CARRIAGE RETURN [transparent, no\_lf: +(transparent)]:  
BITS PER CHARACTER [8bits, 7bits: +(8bits)]:

*If SERVICE TYPE is "ip\_to\_bns":*

HUNT GROUP PORT [1-65535: +(23)]:  
CUG LIST [1-32,0 for none: +(0)]:



### **Enter and Change - Component “vport” continued**

*If SERVICE TYPE is “bns\_to\_ip”:*

**DESTINATION IP ADDRESS [decimal dot notation: +(none)]:**

**DESTINATION TCP PORT [1-65535: +(none)]:**

**DESTINATION PDD ID [1-16 | 0 for none +(0)]:**

**PEER TO PEER ENCRYPTION [transparent, encrypt:  
+(transparent)]:**

*If module SERVICE STATE is “out”:*

**INITIAL SERVICE STATE [in, out: +(out)]:**

*The command then loops back to the VPORT NUMBER prompt.*

Vports are entered as single ports or *ranges* of ports. The specific values of parameters chosen for the vports in a range generate a single IP configuration. Changes to that configuration should also be input as a range. If a parameter value for a single vport within a range is changed, the range will be split into multiple ranges that cannot be rejoined. Corresponding and multiple IP configurations will be generated. For example, if vport 1-200 are entered, there is one IP configuration for all of these ports. If vport 100 is changed, there will now be three ranges and three IP configurations: vports 1-99, vport 100 and vports 101-200. This is obvious in the verify report output.

### **Enter and Change - continued**

***If COMPONENT is “cug”:***

*(The following prompts correspond to the parameters in the “cug” command on the UMI console.)*

**MODULE ADDRESS:**

**CUG NUMBER [1-32]:**

**CUG IP ADDRESS [decimal dot notation: +(none)]:**

**CUG SUBMASK [decimal dot notation: +(none)]:**

*The command then loops back to the CUG NUMBER prompt.*



**Enter and Change - continued**

**If COMPONENT is "host":**

(The following prompts correspond to the parameters in the "host" command on the UMI console.)

MODULE ADDRESS:  
HOST ID [1-16]:  
HOST NAME:  
HOST IP ADDRESS [decimal dot notation: +(none)]:  
HOST TCP PORT [1-65535]:

The command then loops back to the HOST ID prompt.

**If COMPONENT is "pdd":**

(The following prompts correspond to the parameters in the "pdd" command on the UMI console. This command allows the specification of mnemonic addresses instead of numeric IP addresses.) **Note: This functionality can only be used if the UMI has a DTK41 IO board installed.** If the board is not present on the UMI this configuration will be ignored by the UMI.

MODULE ADDRESS:  
DESTINATION PDD ID [1-16]:  
DESTINATION PDD ADDRESS: [up to 63 characters not double  
quoted | none]

(The word "none" is reserved. Its deletes a PDD address. It cannot be used as a valid PDD address name.)

The command then loops back to the DESTINATION PDD ID prompt.



### 5.3 Verify

```
CC0> verify
OBJECT: [...umi...]
COMPONENT: [module, vport, host, cug, pdd]
```

**If COMPONENT is “module”:**

```
MODULE ADDRESS: [+(all)]:
```

*The format of a sample output report is:*

```
02-04-12 12:59:16 NODE=tweety
M verify umi module 17
MODULE ADDRESS: 17
MODULE TYPE: umi                NCHLS: 512
SERVICE STATE: out (manual)
DOWNLOAD SERVER: controller
VERSION: standard
GATEWAY ADDRESS: 0.0.0.0
LOCAL IP ADDR:   0.0.0.0        LOCAL SUBMASK:  0.0.0.0
SNMP IP ADDR:   0.0.0.0        SNMP PORT:      0
DNS1 IP ADDR:   0.0.0.0
DNS2 IP ADDR:   0.0.0.0
DNS3 IP ADDR:   0.0.0.0

DNS NAME1:
DNS NAME2:
DNS NAME3:

COMMENT:
```



**Verify - continued**

If the **COMPONENT** is "vport":

**MODULE ADDRESS:**

**VPORT NUMBER [1-504: +(1-504)]: +**

The format of a sample output report is:

02-04-12 16:14:40 NODE=tweety

M verify umi vport 17 1-504

MODULE ADDRESS: 17

MODULE TYPE: umi

NCHLS: 512

SERVICE STATE: out (manual)

DOWNLOAD SERVER: controller

VERSION: standard

GATEWAY ADDRESS: 0.0.0.0

LOCAL IP ADDR: 0.0.0.0

LOCAL SUBMASK: 0.0.0.0

SNMP IP ADDR: 0.0.0.0

SNMP PORT: 0

DNS1 IP ADDR: 0.0.0.0

DNS2 IP ADDR: 0.0.0.0

DNS3 IP ADDR: 0.0.0.0

DNS NAME1:

DNS NAME2:

DNS NAME3:

COMMENT:

Virtual Port Number 1 to 200

Service State ==> out

Service Type ==> ip\_to\_bns

Group ==> umiorig

Protocol ==> async

PDD ==> luna3

Hunt Group Port ==> 23

CUG list ==> 1,3-5

Session Hold ==> On



**Verify - Component "vport" continued**

```
Attention Character ==> lbrk
Attention Action ==> command
Null after CR ==> Transparen
LF after CR ==> On
Bits Per Character ==> 8bit
Peer to Peer Encryption ==> Transparent
COMMENT
```

```
Virtual Port Number 201 to 300
Service State ==> out
Service Type ==> bns_to_ip
Group ==> umircv
Protocol ==> synchronous
Destination IP Address ==> 192.168.8.8 TCP Port 5000
Peer to Peer Encryption ==> Transparent
COMMENT    new comment
```

```
02-04-12 16:14:40 NODE=tweety
```

```
M verify umi vport 17 1-504
```

```
Virtual Port Number 301 to 301
Service State ==> out
Service Type ==> ip_to_bns
Group ==> umiorig
Protocol ==> async
PDD ==> none
Hunt Group Port ==> 23
CUG list ==> 0
Session Hold ==> off
Null after CR ==> Transparent
LF after CR ==> Transparent
Bits Per Character ==> 8bit
Peer to Peer Encryption ==> Transparent
```



## Verify - Component “vport” continued

### COMMENT

Note that the content of the **verify umi vport** report will depend on the type of PROTOCOL and SERVICE TYPE for a range of ports. The output will differ for “async” versus “sync” or “raw”, and “bns\_to\_ip” versus “ip\_to\_bns”.

## Verify - continued

If COMPONENT is “host”:

MODULE ADDRESS:

HOST ID [+(1-16)]:

The format of a sample output report is:

```
02-04-12 12:58:10 NODE=tweety
M verify umi host 17
MODULE ADDRESS: 17
MODULE TYPE: umi NCHLS: 512
SERVICE STATE: out (manual)
DOWNLOAD SERVER: controller
VERSION: standard
GATEWAY ADDRESS: 0.0.0.0
LOCAL IP ADDR: 0.0.0.0 LOCAL SUBMASK: 0.0.0.0
SNMP IP ADDR: 0.0.0.0 SNMP PORT: 0
DNS1 IP ADDR: 0.0.0.0
DNS2 IP ADDR: 0.0.0.0
DNS3 IP ADDR: 0.0.0.0

DNS NAME1:
DNS NAME2:
DNS NAME3:

COMMENT:

HOST ID->6 HOST NAME->pamela
IP ADDRESS->1.2.3.4 TCP PORT->5000
```



**Verify** - continued

If COMPONENT is "cug":

MODULE ADDRESS:

CUG NUMBER [1-32: +(1-32)]:

The format of a sample output report is:

```
M verify umi cug 17
MODULE ADDRESS: 17
MODULE TYPE: umi                NCHLS: 512
SERVICE STATE: out (manual)
DOWNLOAD SERVER: controller
VERSION: standard
GATEWAY ADDRESS: 0.0.0.0
LOCAL IP ADDR: 0.0.0.0         LOCAL SUBMASK: 0.0.0.0
SNMP IP ADDR: 0.0.0.0         SNMP PORT: 0
DNS1 IP ADDR: 0.0.0.0
DNS2 IP ADDR: 0.0.0.0
DNS3 IP ADDR: 0.0.0.0

DNS NAME1:
DNS NAME2:
DNS NAME3:

COMMENT:

CUG ID->1 IP ADDRESS->122.122.2.2
          IP SUBMASK->255.255.255.0

CUG ID->3 IP ADDRESS->192.168.22.22
          IP SUBMASK->255.255.0.0
```



**Verify** - *continued*

If **COMPONENT** is "pdd":

**MODULE ADDRESS:**  
**DESTINATION PDD ID [(+)(1-16)]:**

The format of a sample output report is:

```
02-04-12 12:58:10 NODE=tweety
M verify umi pdd 17 1-16

MODULE ADDRESS: 17
MODULE TYPE: umi NCHLS: 512
SERVICE STATE: out (manual)
DOWNLOAD SERVER: controller
VERSION: standard
GATEWAY ADDRESS: 0.0.0.0
LOCAL IP ADDR: 0.0.0.0 LOCAL SUBMASK: 0.0.0.0
SNMP IP ADDR: 0.0.0.0 SNMP PORT: 0
DNS1 IP ADDR: 0.0.0.0
DNS2 IP ADDR: 0.0.0.0
DNS3 IP ADDR: 0.0.0.0

DNS NAME1:
DNS NAME2:
DNS NAME3:
COMMENT:

Destination PDDs
PDD ID->1 PDD->nj/dtk/tweety
PDD ID->2 PDD->homeaddress
```



## 5.4 Remove and Restore

```
CC0> remove or restore  
OBJECT: [...umi...] umi  
COMPONENT [module, vport]:
```

*If COMPONENT is “module”:*

```
MODULE ADDRESS:
```

*If the COMPONENT is “vport”:*

```
MODULE ADDRESS:
```

```
VPORT NUMBER [1-504: +(1-504)]:
```

The **restore umi mod** command will restore the **UMI** module and any *ready for service (RFS)* vports. It will download the IP configuration data entered for the module, ready for service ports, hosts and cugs.

If the module address is already in service, the **restore umi vport** command will restore the vport or ports and send the vport configuration information to the module. If the module is out of service, the vport or ports will be marked *RFS*.

The **remove umi mod** command will take the **UMI** module out of service and mark any in service vports as *RFS*.

## 5.5 Delete

When deleting a **UMI** module, all the vports must be deleted first. CUGS, pdds and hosts for that **UMI** do not. They will be automatically deleted when the module is deleted.

```
CC0> delete  
OBJECT: [...umi...] umi  
COMPONENT: [module, vport, cug, host]
```

*If COMPONENT is “module”:*

```
MODULE ADDRESS:
```

*If the COMPONENT is “vport”:*

```
MODULE ADDRESS:
```

```
VPORT NUMBER [1-504: +(1-504)]:
```



**Delete - continued**

*If COMPONENT is "cug":*

MODULE ADDRESS:  
CUG NUMBER [1-32]:

*If COMPONENT is "host":*

MODULE ADDRESS:  
HOST ID [1-16]:

The "delete" command is *not* used to delete a **pdd** from the pdd address table. To delete a **pdd** address, do a "chg umi" and select "**pdd**". Set the address to the value "**none**".

```
CC0> change or chg
OBJECT: [...umi...] umi
COMPONENT: [module, vport, cug, host, pdd]
```

*If COMPONENT is "pdd":*

```
MODULE ADDRESS:
DESTINATION PDD ID [1-16]: [select index of pdd to be deleted]
DESTINATION PDD ADDRESS: none
```

Note that if a **destination pdd address** is deleted from the pdd table by using the above sequence, the **destination pdd id** is no longer defined. A **vport** that previously has had its **destination pdd id** set to this index value will still have the value of its **destination pdd id** set to this index even though the **pdd** has no address value.

The "delete" command is also *not* used to delete the value of a **destination pdd id** from a **vport** definition. To delete the value of a **destination pdd id** from a **vport**, do a "chg umi" and select "**vport**". Set the "**destination pdd id**" to a numeric zero (0). This affects only this **vport**.



### 5.6 SAM - Based Commands

Two commands, **display measurements (dmeas)** and **display status (dstat)** work for the **UMI** module in the following way: When either command is input, use the OBJECT: **SAM** instead of **UMI** when the module is actually a **UMI** and not a SAM trunk module. These commands treat the **UMI** as a SAM504 in the command syntax and refer to SAM board and port. Therefore, a translation has to be done between the **UMI** vport number and the comparable SAM504 board and port. The following table provides that translation:

BNS Controller (SAM504) Board/Port ←-----→ UMI Virtual Port mapping

<b>SAM504 Board/Port Numbers</b>	<b>UMI Virtual Port Numbers</b>
Board 1 Ports 1-32	Ports 1-32
Board 2 Ports 1-32	Ports 33-64
Board 3 Ports 1-32	Ports 65-96
Board 4 Ports 1-32	Ports 97-128
Board 5 Ports 1-32	Ports 129-160
Board 6 Ports 1-32	Ports 161-192
Board 7 Ports 1-32	Ports 193-224
Board 8 Ports 1-32	Ports 225-256
Board 9 Ports 1-32	Ports 257-288
Board 10 Ports 1-32	Ports 289-320
Board 11 Ports 1-32	Ports 321-352
Board 12 Ports 1-32	Ports 353-384
Board 13 Ports 1-32	Ports 385-416
Board 14 Ports 1-32	Ports 417-448
Board 15 Ports 1-32	Ports 449-480
Board 16 Ports 1-24	Ports 481-504

The report output for either command acknowledges that the module is a **UMI** module and includes that in the output.



### 5.6.1 Display Measurements

The validation routines will recognize the **UMI** community type. The **dmeas sam** command process will display all single link measurements currently reported for the SAM504.

```
CCO> dmeas sam
```

*The rest of the prompts are the same as for a SAM504.*

### 5.6.2 Display Status

The validation routines for the **dstat sam** and **dstat module** command processes will recognize the UMI community type. The reports will display the same information as that provided for the SAM504.

```
CCO> dstat sam
```

*The rest of the prompts are the same as for a SAM504*

### 5.6.3 Verify Comment

Select SAM as the object for Verify. The output report will show UMI as the type for those modules that are defined as UMIs and SAM for those defined as SAMs.



## 6 APPENDIX – COMMAND/PARAMETER COMPARISON TABLE

UMI Module Command/Parameters	BNS/Datakit Command/Parameters	Comments
admpass	No comparable BNS UMI module command	<b>Enter node</b> command administers password for the <i>node console</i>
chgpas	No comparable BNS UMI module command	<b>Change node</b> command administers password for the <i>node console</i>
clear	No comparable BNS module command	
console	No comparable BNS module command	Can administer BNS <i>node console</i> security using <b>enter</b> and <b>change</b> node commands.
cug - cug number, ipaddr, submask	Enter/chg/del umi cug – module address, cug number, cug ip address, cug submask	
dconn	Display connections - type	Information in BNS report not same as UMI module dconn report
disc vport –vport#	Remove /restore umi vport – module address, vport number	
disc console	No comparable BNS module command	
dm mod	Dmeas sam module – module, interval	Actual module in BNS node is UMI
dm vport – vport #	Dmeas sam port – module address, interval, board, port	Actual module in BNS node is UMI
dns – ipaddrX, nameX	Enter/chg umi module – module address, dns ip address X, domain name X	
gateway – ipaddr	Enter/chg umi module – module address, gateway address	

## COMMAND/PARAMETER COMPARISON TABLE (CONTINUED)

UMI Module Command/Parameters	BNS/Datakit Command/Parameters	Comments
help	Help or dkhelp (from StarKeeper II NMS)	
host host # -name, ipaddr, port	Enter/chg umi host – module address, host id, host ip address, host tcp port	
host host # - del	Delete umi host – module, host id	
hpio reset	No comparable BNS UMI module command	
hpio enable - all	No comparable BNS UMI module command	
hpio disable - all	No comparable BNS UMI module command	
hpio enable – fiber, 10/100 phy range	No comparable BNS UMI module command	
hpio disable – fiber, 10/100 phy range	No comparable BNS UMI module command	
Install	No comparable BNS UMI module command	New UMI module software must be installed via UMI hardware/telnet console – not available as a node controller option
label	No comparable BNS UMI module command	
local –ipaddr, submask	Enter/chg umi module – module address, local ip address, local ip submask	
login/logout	No comparable BNS UMI module command	
pdd	Enter/chg umi pdd – module address, destination pdd id, destination pdd address	
ping	No comparable BNS node command	Can ping from StarKeeper if StarKeeper host is connected to IP network
reboot	Remove/restore umi module – module address	



## COMMAND/PARAMETER COMPARISON TABLE (CONTINUED)

UMI Module Command/Parameters	BNS/Datakit Command/Parameters	Comments
remove	Remove umi module – module address	
restore	Restore umi module – module address	
snmp – ipaddr, port	Enter/chg umi module – module address, snmp ip address, snmp udp port	
snmp - cug	Enter/chg umi module – module address, snmp cug list	
timeout	No comparable BNS UMI module or node command	Node console has non- settable timeout for command input
uprompt	No comparable BNS UMI module command	
version	No comparable BNS UMI module command	
vfy mod	Verify umi module – module address	
vfy vport	Verify umi vport – module address, vport number	
vfy cug	Verify umi cug – module address, cug number	
vfy host	Verify umi host – module address, host id	
vport ( see next page)		



## COMMAND/PARAMETER COMPARISON TABLE (CONTINUED)

UMI Module Command/Parameters	BNS/Datakit Command/Parameters	Comments
vport – vport #, cnt, incr	Enter/chg/del umi vport – module address, vport number	
vport – vport #, type	Enter/chg/del umi vport – module address, vport number, service type	
vport – vport #, pdd	Enter/chg umi vport – module address, vport number, destination pdd id	
vport – vport #, dest	Enter/chg/del umi vport – module address, vport number, destination ip address	
vport – vport #, dport	Enter/chg/del umi vport – module address, vport number, destination tcp port	
vport – vport #, hport	Enter/chg/del umi vport – module address, vport number, hunt group port	
vport – vport #, cug	Enter/chg/del umi vport – module address, vport number, cug list	
vport – vport #, prot	Enter/chg/del umi vport – module address, vport number, protocol	
vport – vport #, crfix	Enter/chg/del umi vport – module address, vport number, null after carriage return	
vport – vport #, crlf	Enter/chg/del umi vport – module address, vport number, lf after carriage return	
vport – vport #, data	Enter/chg/del umi vport – module address, vport number, bits per character	



## COMMAND/PARAMETER COMPARISON TABLE (CONTINUED)

UMI Module Command/Parameters	BNS/Datakit Command/Parameters	Comments
vport – vport #, session	Enter/chg/del umi vport – module address, vport number, session hold, attention character, attention action	
vport – vport #, crypt	Enter/chg/del umi vport – module address, vport number, peer to peer encryption	

## 7 HARDWARE WARRANTY

The warranty period for hardware shall be one year from the date of delivery. Replacements and repairs are guaranteed for the longer of the remaining original warranty period or 90 days.

## 8 END-USER LICENSE AGREEMENT FOR SOFTWARE

This License Agreement ("License") is a legal contract between you and the manufacturer ("Manufacturer") of the system ("HARDWARE") with which you acquired software product(s) identified above ("SOFTWARE"). The SOFTWARE may include printed materials that accompany the SOFTWARE. Any software provided along with the SOFTWARE that is associated with a separate end-user license agreement is licensed to you under the terms of that license agreement. By installing, copying, downloading, accessing or otherwise using the SOFTWARE, you agree to be bound by the terms of this LICENSE. If you do not agree to the terms of this LICENSE, Manufacturer is unwilling to license the SOFTWARE to you. In such event, you may not use or copy the SOFTWARE, and you should promptly contact Manufacturer for instructions on return of the unused product(s) for a refund.

### 8.1 Software License

You may only install and use one copy of the SOFTWARE on the HARDWARE (unless otherwise licensed by Manufacturer). The SOFTWARE may not be installed, accessed, displayed, run, shared or used concurrently on or from different computers, including a workstation, terminal or other digital electronic device ("Devices"). Notwithstanding the foregoing and except as otherwise provided below, any number of Devices may access or otherwise utilize the services of the SOFTWARE. You may not reverse engineer, decompile, or disassemble the SOFTWARE, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation. The SOFTWARE is licensed as a single product. Its component parts may not be separated for use on more than one HARDWARE. The SOFTWARE is licensed with the HARDWARE as a single integrated product. The SOFTWARE may only be used with the HARDWARE as set forth in this LICENSE. You may not rent, lease or lend the SOFTWARE in any manner. You may permanently transfer all of your rights under this LICENSE only as part of a permanent sale or transfer of the HARDWARE, provided you retain no copies, you transfer all of the SOFTWARE (including all component parts, the media and printed materials, any upgrades, this LICENSE and, if applicable, the Certificate(s) of Authenticity), and the recipient agrees to the terms of this LICENSE. If the SOFTWARE is an upgrade, any transfer must also include all prior versions of the SOFTWARE. Without prejudice to any other rights, Manufacturer may terminate this LICENSE if you fail to comply with the terms and conditions of this LICENSE. In such event, you must destroy all copies of the SOFTWARE and all of its component parts.

### 8.2 Intellectual Property Rights

The SOFTWARE is licensed, not sold to you. The SOFTWARE is protected by copyright laws and international copyright treaties, as well as other intellectual property laws and treaties. You may not copy the printed materials accompanying the SOFTWARE. All title and intellectual property rights in and to the content which may be accessed through use of the SOFTWARE is the property of the respective content owner and may be protected by applicable copyright or other intellectual property laws and treaties. This LICENSE grants you no rights to use such content. All rights not expressly granted under this LICENSE are reserved Manufacturer and its licensors (if any).



### **8.3 Software Support**

SOFTWARE support is not provided by Manufacturer, or its affiliates or subsidiaries separate from the HARDWARE. For SOFTWARE support, please contact your supplier of the HARDWARE. Should you have any questions concerning this LICENSE, or if you desire to contact Manufacturer for any other reason, please refer to the address provided in the documentation for the HARDWARE.

### **8.4 Export Restrictions**

You agree that you will not export or re-export the SOFTWARE to any country, person, or entity subject to U.S. export restrictions. You specifically agree not to export or re-export the SOFTWARE: (i) to any country to which the U.S. has embargoed or restricted the export of goods or services, which as of March 1998 include, but are not necessarily limited to Cuba, Iran, Iraq, Libya, North Korea, Sudan and Syria, or to any national of any such country, wherever located, who intends to transmit or transport the products back to such country; (ii) to any person or entity who you know or have reason to know will utilize the SOFTWARE or portion thereof in the design, development or production of nuclear, chemical or biological weapons; or (iii) to any person or entity who has been prohibited from participating in U.S. export transactions by any federal agency of the U.S. government.

### **8.5 Limited Warranty**

Manufacturer warrants that (a) the SOFTWARE will perform substantially in accordance with the accompanying written materials for a period of ninety (90) days from the date of receipt. Any implied warranties on the SOFTWARE are limited to ninety (90) days. Some states/jurisdictions do not allow limitations on duration of an implied warranty, so the above limitation may not apply to you.

Manufacturer's and its suppliers' entire liability and your exclusive remedy shall be, at Manufacturer's option, either (a) return of the price paid, or (b) repair or replacement of the SOFTWARE that does not meet this Limited Warranty and which is returned to Manufacturer with a copy of your receipt. This Limited Warranty is void if failure of the SOFTWARE has resulted from accident, abuse, or misapplication. Any replacement SOFTWARE will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer.

### **8.6 No Other Warranties**

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, MANUFACTURER AND ITS SUPPLIERS DISCLAIM ALL OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT, WITH REGARD TO THE SOFTWARE AND THE ACCOMPANYING WRITTEN MATERIALS. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHERS, WHICH VARY FROM STATE/JURISDICTION TO STATE/JURISDICTION.

### **8.7 Special Provisions**

The SOFTWARE and documentation are provided with RESTRICTED RIGHTS. Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and HARDWARE Software clause at DFARS 252.227-7013 or subparagraphs (c)(1) and (2) of the Commercial HARDWARE Software-Restricted Rights at 48 CFR 52.227-19, as applicable. Manufacturer is Datatek Applications, Inc., Rte. 202-206, Bridgewater, New Jersey 08807.



If you acquired the SOFTWARE in the United States of America, this Software License are governed by the laws of the State of New Jersey, excluding its choice of laws provisions. If you acquired the SOFTWARE outside the United States of America, local law may apply. This LICENSE constitutes the entire understanding and agreement between you and the Manufacturer in relation to the SOFTWARE and supercedes any and all prior or other communications, statements, documents, agreements or other information between the parties with respect to the subject matter hereof.

## 9 LIMITATION OF LIABILITY

**To the maximum extent permitted by applicable law, in no event shall Manufacturer or its suppliers be liable for any damages whatsoever (including without limitation, special, incidental, consequential, or indirect damages for personal injury, loss of business profits, business interruption, loss of business information, or any other pecuniary loss) arising out of the use of or inability to use this product, even if Manufacturer has been advised of the possibility of such damages.** In any case, Manufacturer's and its suppliers' entire liability under any provision of this License shall be limited to the amount actually paid by you for the SOFTWARE and/or the HARDWARE. Because some states/jurisdictions do not allow the exclusion or limitation of liability for consequential or incidental damages, the above limitation may not apply to you.

©Copyright 2002 Datatek Applications Inc.

©Copyright 2002 TeleComp, Inc.

All Rights Reserved

Printed in USA

