

**Data**tek



**INSTALLATION AND ADMINISTRATION  
GUIDE**

**FOR HP-UX®**

**RELEASE 1.0.22**

**ISSUE 2**

379 Campus Drive, Suite 100  
Somerset, NJ 08873  
fax: 732.667.1091  
phone: 732.667.1080  
email: [sales@datatekcorp.com](mailto:sales@datatekcorp.com)  
<http://www.datatekcorp.com>



## TABLE OF CONTENTS

<b>1</b>	<b>INTRODUCTION</b> .....	<b>4</b>
1.1	What is IP-CommKit? .....	4
<b>2</b>	<b>DOCUMENTATION</b> .....	<b>5</b>
<b>3</b>	<b>INSTALLATION AND CONFIGURATION</b> .....	<b>6</b>
3.1	Overview .....	6
3.2	IP Addresses.....	6
3.3	UTM Installation.....	8
3.4	BNS Node Configuration.....	10
3.5	Software Installation .....	14
3.5.1	Prerequisites.....	14
3.5.2	Removing CommKit Host Interface Software .....	14
3.5.3	Installing IP-CommKit Software.....	15
3.5.4	Registration .....	18
3.6	Customize the Control Tables .....	21
3.6.1	dkiptab.....	21
3.6.2	dkitrc and dkitcfg .....	21
3.6.3	dksrvtab .....	22
<b>4</b>	<b>CONTROL TABLES</b> .....	<b>23</b>
<b>5</b>	<b>ADMINISTRATION</b> .....	<b>24</b>
5.1	Files That Grow .....	24
5.2	dkitrc Script File .....	24
5.3	Special Device Files .....	24
5.4	Printer Administration.....	25
<b>6</b>	<b>TROUBLESHOOTING</b> .....	<b>26</b>
6.1	Overview .....	26
6.2	Procedures.....	26



**IP-CommKit Installation and Administration Guide  
for HP-UX – Issue 2 – Release 1.0.22**

6.2.1	Check that the UTM is in service .....	26
6.2.2	Check that the CPM is in service.....	27
6.2.3	Check the Mode Switch on the UTM .....	29
6.2.4	Ping the UTM from the host .....	30
6.2.5	Check /var/opt/dk/dkipdlog .....	30
6.2.6	Check /var/opt/dk/log/dkdaemonlog .....	32
6.2.7	Check /var/opt/dk/dksrvlog .....	34
6.3	Stopping and Starting .....	37
7	COMPATIBILITY.....	38
8	MANUAL PAGES .....	39
9	END-USER LICENSE AGREEMENT FOR SOFTWARE .....	40
9.1	SOFTWARE LICENSE .....	40
9.2	INTELLECTUAL PROPERTY RIGHTS.....	40
9.3	SOFTWARE SUPPORT.....	41
9.4	EXPORT RESTRICTIONS .....	41
9.5	LIMITED WARRANTY .....	41
9.6	NO OTHER WARRANTIES .....	41
9.7	SPECIAL PROVISIONS.....	42
9.8	LIMITATION OF LIABILITY .....	42




# 1 INTRODUCTION

## 1.1 WHAT IS IP-COMMKIT™?

IP-CommKit is a new twist on the CommKit® Host Interface for BNS-2000 and BNS-2000 VCS (a.k.a. Datakit® II VCS). Where the CommKit Host Interface uses a fiber optic cable to connect the host computer to the BNS node, IP-CommKit uses a 10Base-T LAN. Instead of a fiber interface card in the host computer, IP-CommKit uses the host's standard LAN interface card. In the BNS node, use of IP-CommKit requires replacement of the CPM Module with a Universal Trunk Module (UTM).

All of these changes are invisible to the host applications and the BNS network. Host applications and CommKit features behave identically. No need to recompile your applications.

### Host and Node Interfaces



™ IP-CommKit is a trademark of Alcatel-Lucent, Inc., licensed to Datatek Applications, Inc., a company independent of Alcatel-Lucent, Inc.

® Datakit is a registered trademark of Alcatel-Lucent, Inc., licensed to Datatek Applications, Inc., a company independent of Alcatel-Lucent, Inc.



## **2 DOCUMENTATION**

Since IP-CommKit behaves like a CommKit Host Interface, you can use the CommKit Host Interface documentation to find answers to most questions. Specifically, use the *CommKit Host Interface for NCR PCI Computers Installation and Administration Guide*. This document follows the same general outline, i.e., it has the same major sections in the same order. Where there are changes or additions for IP-CommKit, they are described in the appropriate section of this document. While NCR computers running MP-RAS are very different from HP® computers running HP-UX, IP-CommKit is built from source code that was ported from the release of the CommKit Host Interface that ran on NCR computers. As a result, much of the information in the *CommKit Host Interface for NCR PCI Computers Installation and Administration Guide* applies to IP-CommKit running on HP computers.

---

® HP-UX and HP are registered trademarks of Hewlett Packard, Inc. Systems Division.

---



## **3 INSTALLATION AND CONFIGURATION**

### **3.1 OVERVIEW**

This section describes the procedures for connecting a host computer to a Lucent Technologies BNS-2000 or BNS-2000 VCS network using IP-CommKit.

This section supercedes the *Installation and Configuration* section of the *CommKit Host Interface for NCR PCI Computers Installation and Administration Guide*.

This section references procedures in the *UTM User's Manual*. Have it handy before you begin.

This section assumes that your host computer is already connected to a LAN. If it's not, you should follow the procedures supplied with your computer for connecting it to a LAN.

Installation and configuration of IP-CommKit consists of the following steps:

- Obtain an IP address for the UTM and determine the appropriate subnet mask. Also determine the host IP address and, if needed, a gateway IP address.
- Install the UTM and I/O distribution board in the BNS node.
- Configure the UTM through its console port.
- Configure the UTM in the BNS node's controller database.
- Install the IP-CommKit software on the host computer
- Customize the dkiptab and, if needed, dkicfg and the other control tables.

The following sections describe each step in detail.

### **3.2 IP ADDRESSES**

This section assumes a basic knowledge of IP networks. If you don't have this knowledge, we recommend that you learn a little about them. We recommend *Internetworking with TCP/IP*, by Douglas E. Comer. Otherwise, enlist the help of your IP network administrator.



## IP-CommKit Installation and Administration Guide for HP-UX – Issue 2 – Release 1.0.22

Each UTM requires an IP address, as does the host computer. You should obtain IP addresses for UTMs from your IP network administrator. This document assumes that the host computer is already connected to a LAN, and thus already has an IP address assigned to it. If your host connects to several LANs, it will have several IP addresses assigned to it, one for each LAN. You should find out the addresses assigned to the LAN that the host will use for communicating with the UTM. You need the host's IP addresses in numeric form for configuring the UTM. To obtain this, take a look at the file `/etc/rc.config.d/netconf` with `pg`, `vi`, or whatever you like to use to look at text files. It is a shell script provided by HP that configures the LAN interfaces on your machine at boot time. This file contains good comments from the HP developers, but the important lines are the assignments to array variables with the name `IP_ADDRESS` and `SUBNET_MASK`. Here is a sample of the relevant lines:

```
INTERFACE_NAME[0]=lan0  
IP_ADDRESS[0]=135.17.59.216  
SUBNET_MASK[0]=255.255.255.0
```

This host has one LAN interface named `lan0`, and its assigned IP address is 135.17.59.216.

To configure the UTM, you also need the *subnet mask* for the IP subnet to which it attaches. Most often, an IP subnet corresponds to a LAN segment. For example, all interfaces attached to the same 10Base-T hub are on the same LAN segment, and almost always have the same subnet mask. If the host and UTM connect to the same subnet, you can find out the subnet mask from the `/etc/rc.config.d/netconf` file. In the previous example, the subnet mask is 255.255.255.0.

If the host and UTM do not attach to the same subnet, your IP network administrator must provide you with an appropriate subnet mask for the UTM. In addition, the administrator must provide you with the IP address of a gateway router. This gateway must reside on the same subnet as



the UTM, and must know how to route packets from the UTM to the host computer. Again, you need the gateway address in numeric form.

### **3.3 UTM INSTALLATION**

Consult the *UTM User's Manual*, Section 3, for instructions on how to install the UTM and I/O distribution board in the BNS node.

After you have installed the UTM and I/O distribution board in the BNS node, you must configure the UTM. The initial configuration of the UTM must be done through its console port. You can access the UTM console port in a variety of ways. For example, you can connect a “dumb” terminal directly to the console port on the I/O distribution board. You can also connect the console port into the BNS network through a SAM or TY module, and then access the console through a terminal or host that is connected to the network. Section 3 of the *UTM User's Manual* shows how to make connections to the UTM's console port.

To configure the UTM, you need an IP address and subnet mask that you will assign to the UTM, as well as the IP address assigned to the host LAN interface. If the UTM and host are not on the same subnet, you will also need the IP address of a gateway that can forward packets from the UTM to the host.

Enter the following commands on the UTM console port.

```
<TRK-UNIV> login passwd=initial
```

```
<TRK-UNIV> rm
```



## IP-CommKit Installation and Administration Guide for HP-UX – Issue 2 – Release 1.0.22

```
<TRK-UNIV> trk type=IPDSU
```

```
<TRK-UNIV> trk modtype=CPM
```

```
<TRK-UNIV> lo ipaddr=utm_ip_address submask=utm_subnet_mask
```

```
<TRK-UNIV> ga ipaddr=gateway_ip_address
```

```
<TRK-UNIV> trk dest=host_ip_address
```

Here the IP addresses and subnet mask are shown in ***bold Italics***. You would replace these names with numbers when you enter the commands.

Enter the following command to check the configuration:

```
<TRK-UNIV> vfy mod
```

The output should be similar to the report below.

Current Configuration:

```
DK Board Type ==> TN1009 (CPM-HS) w/Serial# 136.
```

```
Service State ==> Out of Service.
```

```
Operating Mode ==> Simplex.
```

```
Trunk Type ==> IP-DSU Compatible Trunk on 10BaseT Network Port.
```



## IP-CommKit Installation and Administration Guide for HP-UX – Issue 2 – Release 1.0.22

IP-DSU Loopback Status ==> Loopbacks are not enabled.

IP-DSU Data Encryption Status ==> Disabled.

Actual IP-DSU Service State ==> Not Connected.

Local MAC Address ==> 0.19.5.84.49.56

Local IP Address ==> *utm\_ip\_address*

Subnet Mask ==> *subnet\_mask*

Gateway IP Address ==> *gateway\_ip\_address*

IP-DSU Destination IP Address ==> *host\_ip\_address*

SNMP Trap Manager ==> Not defined.

Check the address and subnet mask fields that you entered. If they are correct, enter the following command to restore the UTM to service.

```
<TRK-UNIV> rs
```

The UTM has many useful console commands that are not described here. See section 4 of the *UTM User's Manual* for a complete description. Once you have done the initial configuration of the UTM through the console port, you can access all console commands through the LAN port via *telnet*. For example, you should be able to *telnet* to the UTM from the host on which you installed the IP-CommKit software.

### 3.4 BNS NODE CONFIGURATION

If you are upgrading a CPM-HS module to a UTM, you don't need to make any changes to the BNS node configuration. You can simply remove the CPM-HS module and its I/O distribution board, and install the UTM and its I/O distribution board in the same slot. The UTM appears as a CPM-HS module to the controller in the BNS node.



## IP-CommKit Installation and Administration Guide for HP-UX – Issue 2 – Release 1.0.22

If this is a new installation, you must configure the UTM in the BNS node's controller database. The following procedure describes a simple configuration. It consists of entering a *group*, an *address* and a *cpm* in the controller database.

Before you begin, pick a name that you will use as this host's address in the BNS network. In configurations using a single dkserver, it's convenient to make this address and the group name the same as the host's nodename. By default, dkserver announces itself to the BNS node by the host's nodename. To determine this name, enter the following command on the host:

```
uname -n
```

This prints the host's nodename. Note that the *uname(1M)* command with no flags is equivalent to *uname -s*. This prints the *system name*, which can be different from the nodename. If you find this confusing, you can use the *setuname(1M)* command to make the system name and node name the same.

If you want to use a name that's different from the host's nodename, you must modify the dkkitcfg file. See section 3.6.2.

Now, enter a group. A group binds together a collection of like modules under one name. In this simple example, there is only one UTM, so the group has only one member. In more complex configurations, you can put up to eight UTMs in one group and distribute incoming calls between these modules using round robin service.

The following dialogue shows the procedure for entering a group on the BNS node console. Text that you type exactly is shown in **bold**, and text that you modify for your installation is shown in ***bold italics***. **<Enter>** and **<Delete>** refer to the enter and delete keys on your keyboard.



## IP-CommKit Installation and Administration Guide for HP-UX – Issue 2 – Release 1.0.22

```
CC0> enter group
```

```
GROUP [up to 8 chars]: nodename
```

```
TYPE [local, trunk: +(local)]: local
```

```
DIRECTION [originate, receive, 2way]: 2way
```

```
DEVICE OR HOST [up to 8 chars: +(standard)]: <Enter>
```

```
PASSWORD [up to 8 chars, none: +(none)]: <Enter>
```

```
ROUND ROBIN SERVICE [per_port, per_module, none: +(none)]: <Enter>
```

```
GROUP [up to 8 chars]: <Delete>
```

Next, enter an address. An address is bound to one or more groups. In this simple example, there is one group, with one UTM in the group. We use the same name for the group and address in this example, although it's not required.

```
CC0> enter address
```

```
LEVEL [network, area, exchange, local, speedcall: +(local)]: <Enter>
```

```
TYPE [numeric, mnemonic, both: +(mnemonic)]: <Enter>
```

```
MNEMONIC ADDRESS [up to 8 chars]: nodename
```

```
PAD SUPPORT [yes, no: +(no)]: <Enter>
```

```
DIRECTORY ENTRY [up to 30 chars double quoted, none: +(none)]:
```

```
"appropriate description of host"
```

```
GROUP(S) [up to 4 groups separated by commas, none: +(none)]:
```

```
nodename
```

```
ORIGINATING GROUP NAME SECURITY PATTERN(S)
```

```
[comma-separated pattern list, same_as, none: +(none)]:
```

---



## IP-CommKit Installation and Administration Guide for HP-UX – Issue 2 – Release 1.0.22

<Enter>

INITIAL SERVICE STATE [in, out: +(out)]: **in**

LEVEL [network, area, exchange, local, speedcall: +(local)]: <Delete>

Next, enter the cpm. In reality, the cpm is a UTM, but the BNS controller can't tell the difference. In the dialog below, you must use values for **mod\_address** and **num\_channels** that are correct for your configuration. Use the slot number where you installed the UTM for the **mod\_address**. By default, dkdaemon(1M) sets the number of channels per UTM to 64, so use this value for **num\_channels**. If you want to use more channels, you must modify the dkitcfg file. See section 3.6.2

CC0> **enter cpm**

MODULE ADDRESS: **mod\_address**

COMMENT [up to 60 chars double quoted, or none: +(none)]:

**"appropriate comment"**

HARDWARE TYPE [422, hs: +(hs)]: <Enter>

NUMBER OF CHANNELS [3-512: +(32)]: **num\_channels**

CALL SCREENING PROFILE ID [up to 8 chars, none: +(none)]: <Enter>

CONNECT-TIME BILLING [on, off: +(off)]: <Enter>

SINGLE OR MULTIPLE GROUPS [single, multiple: +(single)]: <Enter>

GROUP [up to 8 chars]: **nodename**

ENDPOINT NUMBER OR RANGE [0000-9999, none: +(none)]: <Enter>

MODULE ADDRESS: <Delete>



Finally, restore the cpm to service.

```
CC0> restore cpm
```

```
MODULE ADDRESS: mod_address
```

## **3.5 SOFTWARE INSTALLATION**

### **3.5.1 PREREQUISITES**

Before ordering and installing any software on your computer, verify that it is running a release of its operating system that supports IP-CommKit. See the IP-CommKit Release Notes for a list of supported operating system releases. Do not attempt to install the IP-CommKit software if your computer is running an operating system release that is not supported. Also verify the kernel size: 32 or 64-bit and whether the libraries that are used are 32-bit or 64-bit. Also we need to know the number of CPU's/processors in the host. To determine this count, run the following command which is usually in /usr/sbin:

```
$ sar -M -u 1 2
```

Contact us with the output of the command at [ipcommkit@datatekcorp.com](mailto:ipcommkit@datatekcorp.com).

### **3.5.2 REMOVING COMMKIT HOST INTERFACE SOFTWARE**

If you are upgrading a computer from the CommKit Host Interface to IP-CommKit, you must remove the CommKit Host Interface software before installing the IP-CommKit. There are several different versions of the CommKit Host Interface hardware and software for HP computers, so you will need to consult the documentation provided by HP. As an example, for a machine that uses the EISA bus fiber interface board, HP calls the CommKit Host Interface software package for this board *EisaDatakit*. You would use the following procedure to remove it:

First, login as **root**. Now, enter the following command:

---



```
# swremove EisaDatakit
```

However, the software package installed on your machine may have a different name. If you don't have your HP documentation, run the `swlist(1M)` command and look for *Datakit* or *CommKit* in the description fields.

When you remove the software, you may see the following warning:

```
WARNING: The software specified contains a kernel fileset. It will be  
         necessary to reconfigure the kernel and reboot the system to  
         remove the functionality from the kernel.
```

If you plan to proceed immediately with the installation of IP-CommKit, you can ignore the notice about rebooting the machine.

### **3.5.3 INSTALLING IP-COMMKIT SOFTWARE**

If a version of IP-CommKit was previously installed and the directory `/tmp/ipcommkit` is not empty, remove its contents, logged in as root:

```
# cd /tmp/ipcommkit  
# pwd (Verify that you are in the current directory)  
# rm -rf *
```

Use the following procedure to install the IP-CommKit software.



## IP-CommKit Installation and Administration Guide for HP-UX – Issue 2 – Release 1.0.22

The IP-CommKit software is delivered as a .tar file, either on a Compact Disc or electronically. First, login as root, then follow the appropriate procedure.

### 3.5.3.1 COMPACT DISC

Prepare for retrieving the .tar file from the CD:

```
# mkdir /cdrom  
# mount -F cdfs -o cdcase,ro /dev/dsk/c1t2d0 /cdrom
```

Make a directory in which to expand the .tar file and go to that directory:

```
# mkdir /tmp/ipcommkit  
# cd /tmp/ipcommkit
```

Retrieve the .tar file from the CD:

For HPUX R11\_00 32 bit hosts:

```
# tar xf /cdrom/hp_11_00/ipckhp32.tar
```

For HPUX R11\_00 64 bit hosts:

```
# tar xf /cdrom/hp_11_00/ipckhp64.tar
```

For HPUX R11\_11 32 bit hosts:

```
# tar xf /cdrom/hp_11i/ipckhp32.tar
```

For HPUX R11\_11 64 bit hosts:

```
# tar xf /cdrom/hp_11i/ipckhp64.tar
```



## IP-CommKit Installation and Administration Guide for HP-UX – Issue 2 – Release 1.0.22

For HPUX R10\_20 hosts:

```
# tar xf /cdrom/hp_10_20/ipckhp.tar
```

Unmount the CD:

```
# umount /cdrom
```

To install the IP-CommKit software, enter the following command:

```
# swinstall -s /tmp/ipcommkit IPCOMMKIT
```

### 3.5.3.2 .TAR FILE

Instead of receiving a CD, the tar file may have been sent to you electronically. In that case, make a directory in which to expand the tar file.

```
# mkdir /tmp/ipcommkit
```

The name of the .tar file will vary with the release. For example, for HPUX R10\_20, the .tar file is named **ipckhp.tar**.

Move this file to the **/tmp/ipcommkit** directory that you just created, then run the following commands.

```
# cd /tmp/ipcommkit
```

```
# tar xf ipckhp.tar
```



## IP-CommKit Installation and Administration Guide for HP-UX – Issue 2 – Release 1.0.22

```
# swinstall -s /tmp/ipcommkit IPCOMMKIT
```

Your host is now configured to start the IP-CommKit software automatically at boot time. You can reboot your host now, but you will need to register your copy of the software and configure your control tables before you can use IP-CommKit. To reboot your host, enter the following commands:

```
# cd /
```

```
# shutdown -y -r now
```

### 3.5.4 REGISTRATION

Starting with revision 1.0.12, the IP-CommKit software is copy-protected. You must obtain a software key and register your copy of the software before you can use IP-CommKit.

Here is how the registration process works: When you purchase IP-CommKit, we provide you with a *software certificate number*. For example, here is the software certificate number for the IP-CommKit software running on one of my development machines:

**20HP11113-000670-U6CU**

If you received your software on a CD, the software certificate number is included in the package. If the software was delivered electronically, the software certificate number is included in the e-mail message. In either case, you must save the software certificate number since it serves as your proof of purchase.

After installing the IP-CommKit software on your host computer, contact us to obtain a *software key*. To generate your software key, we need your software certificate number and the nodename of the host on which the software is installed. To determine the nodename, enter the following command on the host:

```
$ uname -n
```



## IP-CommKit Installation and Administration Guide for HP-UX – Issue 2 – Release 1.0.22

This prints the host's nodename.

The best way to contact us is to send an e-mail message to the following address:

[ipcommkit@datatekcorp.com](mailto:ipcommkit@datatekcorp.com)

In addition to your software certificate number and your host's nodename, please include your name, company's name, e-mail address and telephone number. Also include the revision number of the IP-CommKit software. This will help us to contact you when maintenance releases are available. To check the revision number of the IP-CommKit software, enter the following command:

```
$ /usr/sbin/swlist -l product IPCOMMKIT
# Initializing...
# Contacting target "spleen"...
#
# Target:  spleen:/
#
# IPCOMMKIT      1.0.22      IP-CommKit for HP-UX
```

In this example, my development host's name is *spleen* and the revision number is 1.0.22

We will send you a reply with a software key that we generate from your software certificate number and your host's nodename. For example, here is the software key for my development machine:

**AK422-2222-2ZBR-5BXP**



## IP-CommKit Installation and Administration Guide for HP-UX – Issue 2 – Release 1.0.22

While e-mail is the best way to obtain a software key, we can also give you one over the telephone. Here are our names and numbers:

Dan Conklin

Senior Project Manager

732 667-1080 X162

Sue Stultz

Chief Operating Officer

732 667-1080 X131

With the software certificate number and software key, you can register the IP-CommKit software on your host. Log in as *root*. If IP-CommKit is running, stop it first (see details in section 6.3) and run the following command:

```
$ /opt/dk/sbin/dkregister
```

The command will prompt you for the software certificate number and the software key, then validate the values that you enter. If they are correct, it will save the registration information on the host's disk. You will need to re-register your IP-CommKit software on this host again when you install subsequent maintenance releases.

It is now a good time to customize your control tables. (If you had just re-registered your IP-CommKit software and do not need to customize your control tables, start IP-CommKit again. See section 6.3 for details.)



## **3.6 CUSTOMIZE THE CONTROL TABLES**

### **3.6.1 DKIPTAB**

(IP-CommKit must be stopped before you update this table. See 6.3 for details.)

The **dkiptab** is a new control file for IP-CommKit that tells the IP-CommKit software the IP addresses assigned to the UTM and the host LAN interfaces. Even if you are upgrading a computer from the CommKit Host Interface to IP-CommKit, you still must enter the **dkiptab** before IP-CommKit will operate. While the installation scripts create a **dkiptab** file in the appropriate directory, it contains only comments. Fortunately, the **dkiptab** is very easy to enter with your favorite text editor. See the manual page (*dkiptab(4)*) for the file format and examples.

### **3.6.2 DKITRC AND DKITCFG**

**/sbin/init.d/dkitrc** is a shell script that starts and stops the IP-CommKit software on the host computer. It is linked into several **/sbin/rc?.d** directories so that it runs automatically when the init state of the host computer changes, i.e., at startup and shutdown. The operation of **dkitrc** is controlled by **/etc/rc.config.d/dkitcfg**.

The **dkitrc** and **dkitcfg** scripts for IP-CommKit are different from the **/sbin/dkit** and **/etc/rc.config.d/dkit** scripts used in some versions of HP's CommKit Host Interface software. If you are upgrading a computer from the CommKit Host Interface to IP-CommKit, and you customized the configuration in **/etc/rc.config.d/dkit script**, you will need to customize the **dkitcfg** script supplied with the IP-CommKit software. The most common reasons for customizing the **dkitcfg** script are to change the number of channels available per interface from the default value of 64, and to change the number of logical interfaces from the default value of 1. The **dkitcfg** script itself contains instructions for making modifications. It should not be necessary to make any modifications to the **dkitrc** script.



### **3.6.3 DKSRVTAB**

If you are upgrading your computer from the CommKit Host Interface to IP-CommKit, it's likely that the tables used by **dkserver** [see *srvtab(4)*] have already been customized. No changes to these tables are needed to use IP-CommKit.

If you are installing IP-CommKit on a computer that has never run the CommKit Host Interface software, the installation script installs a default set of server tables. **/opt/dk/sbin/dkcust** is a script that can automatically customize these default tables. To use **dkcust**, you should know the area and exchange assigned to the BNS node in which you install the UTM. This information can be obtained by entering the *verify node* command on the BNS node console. Ask your BNS node administrator, if you need assistance.

To use **dkcust**, simply run it and answer the questions.



## **4 CONTROL TABLES**

The control tables used for the CommKit Host Interface are identical to those used for IP-CommKit. Refer to *Control Tables* section of the *CommKit Host Interface for NCR PCI Computers Installation and Administration Guide* for a detailed description of the control tables.

IP-CommKit has one additional control table, dkiptab. This file is read by dkipd when it starts to find the IP addresses assigned to the UTM and host LAN interfaces. See the manual page (*dkiptab(4)*) for the file format and examples.



## **5 ADMINISTRATION**

All of the topics discussed in the Administration section of the *CommKit Host Interface for NCR PCI Computers Installation and Administration Guide* apply to IP-CommKit as well. There are few minor changes and additions that are noted below:

### **5.1 FILES THAT GROW**

**dkipd** creates a log file in `/var/opt/dk/log/dkipdlog`. This file will grow continuously, although at a very slow rate compared to other log files, and should be cleaned out periodically by the system administrator.

### **5.2 DKITRC SCRIPT FILE**

In addition to starting **dkdaemon** and **dkserver**, **dkitrc** starts **dkipd**.

### **5.3 SPECIAL DEVICE FILES**

The minor devices for the diagnostic channels, `/dev/dk/diag0`, etc., are not created for IP-CommKit. These devices were used for managing hardware diagnostics for the fiber interface board that is part of the CommKit Host Interface. IP-CommKit uses the LAN interface on your host computer, and thus relies on the hardware diagnostics supplied with the LAN interface.

IP-CommKit has one additional special device file, `/dev/dk/dkip`, tied to minor device number 16384. This device is used exclusively by **dkipd** to initialize the driver when it starts up.



## **5.4 PRINTER ADMINISTRATION**

There are several figures in this section that show fibers connecting hosts to CPM-HS boards in the switches. With IP-CommKit, the hosts are connected to UTMs in the switches through IP networks.



## **6 TROUBLESHOOTING**

### **6.1 OVERVIEW**

This section describes troubleshooting procedures for IP-CommKit. It supercedes the *Troubleshooting* section of the *CommKit Host Interface for NCR PCI Computers Installation and Administration Guide*.

### **6.2 PROCEDURES**

You are most likely to have difficulty with IP-CommKit right after installation. The following sections describe procedures for troubleshooting the most common problems encountered after installation. If you are having difficulty, start with the first procedure and work towards the end. Resist the temptation to skip procedures that seem obvious.

#### **6.2.1 CHECK THAT THE UTM IS IN SERVICE**

Enter the following command on the UTM console port:

```
<TRK-UNIV> vfy mod
```

The output should be similar to the report below.

Current Configuration:

```
DK Board Type ==> TN1009 (CPM-HS) w/Serial# 136.
```

```
Service State ==> In Service.
```

```
Operating Mode ==> Simplex.
```

```
Trunk Type ==> IP-DSU Compatible Trunk on 10BaseT Network Port.
```

---



## IP-CommKit Installation and Administration Guide for HP-UX – Issue 2 – Release 1.0.22

IP-DSU Loopback Status ==> Loopbacks are not enabled.

IP-DSU Data Encryption Status ==> Disabled.

Actual IP-DSU Service State ==> Not Connected.

Local MAC Address ==> 0.19.5.84.49.56

Local IP Address ==> *utm\_ip\_address*

Subnet Mask ==> *subnet\_mask*

Gateway IP Address ==> *gateway\_ip\_address*

IP-DSU Destination IP Address ==> *host\_ip\_address*

SNMP Trap Manager ==> Not defined.

Specifically, check that the **Service State** is **In Service**. If it's not, enter the following command on the UTM console:

```
<TRK-UNIV> rs
```

### 6.2.2 CHECK THAT THE CPM IS IN SERVICE

Enter the following command on the BNS node console:

```
CC0> dstat mod mod_address
```

In this command, ***mod\_address*** is the slot number where you installed the UTM. The output should be similar to the report below:



**IP-CommKit Installation and Administration Guide  
for HP-UX – Issue 2 – Release 1.0.22**

00-12-18 13:43:46 NODE=*node\_name*

M dstat module *mod\_address*

\*\*\*\*\* MODULE 19 \*\*\*\*\*

MODULE TYPE	SERVICE STATE	HARDWARE ERROR COUNT	SERIAL NUMBER
-------------	---------------	----------------------	---------------

cpmhs	<b>in service</b>	1	136
-------	-------------------	---	-----

LAST HARDWARE ALARM

none

ONLINE ENABLED CABLE AVAIL

yes yes connected yes


Specifically, check that the **SERVICE STATE** is **in service**. If it's not, enter the following command on the node console:

CC0> rs cpm *mod\_address*



### 6.2.3 CHECK THE MODE SWITCH ON THE UTM

Verify the Mode switch on the faceplate of the UTM module is in the **enabl** position. The Mode switch supports three positions: **Enabl**, **Diag** and **Disab**. The Mode switch must be in the **Enabl** position for the UTM to function properly.



#### **6.2.4 PING THE UTM FROM THE HOST**

On the host computer, enter the following command:

```
$ ping utm_ip_address
```

In this command, *utm\_ip\_address* is the IP address that you assigned to the UTM module. The output should be similar to the report below:

```
utm_ip_address is alive
```

If you do not get this output, then the host and UTM cannot exchange packets. In this case, the report would appear as follows:

```
no answer from utm_ip_address
```

If you get this output, check that you are using the correct UTM IP address. If you are, you should enlist the aid of your IP network administrator. Don't proceed until you can *ping* the UTM from the host.

#### **6.2.5 CHECK /VAR/OPT/DK/DKIPDLOG**

Enter the following command on the host computer:

```
$ tail /var/opt/dk/log/dkipdlog
```



**IP-CommKit Installation and Administration Guide  
for HP-UX – Issue 2 – Release 1.0.22**

This displays the end of the log file created by *dkipd*(1M). The last two lines of the output should be similar to the report below:

```
Dec 18 12:08:54 (8626) Connectivity from host_ip_address to utm_ip_address established  
Dec 18 12:09:19 (8626) UTM module utm_ip_address restored to service
```

Here, the *host\_ip\_address* is the IP address assigned to the host computer, and the *utm\_ip\_address* is the IP address assigned to the UTM. Note that *dkipd* will use the name associated with the address, if possible. If your host connects to several UTMs, you should see these two messages repeated for each UTM IP address.

If you see the first line, “Connectivity from ...”, but not the second, “UTM module ...”, it indicates that the CPM is out of service. Go back to the procedure for checking that the CPM is in service.

If the output on your host is different, compare it to the following output examples that are associated with common problems.

```
/opt/dk/sbin/dkipd: Error in configuration file "/etc/opt/dk/dkiptab"  
Line 38: 0    dino  135.17..59.203  
Can't resolve address: 135.17..59.203
```

This output is typical of an error in *dkiptab*, the configuration file for *dkipd*. You may have forgotten to customize the file for you application, or you may have made a typing error. In the output above, there was an error typing in the IP address of the UTM module. Note that the error message indicates the line number where the error was detected.



Dec 18 14:26:38 (8810) Received keep-alive message from unknown address: 135.17.59.203

This output is typical when the UTM IP address you configured in *dkiptab* does not match the UTM IP address you configured through the UTM console.

If the messages that you see don't look similar to any of the examples above, consult the *dkipd(1M)* manual page. This describes all messages that are written to the log file.

The primary responsibility for *dkipd* is to establish communications with the UTM. You can confirm that *dkipd* and the UTM have established communications by issuing the **vfy** command on the UTM console. The report should contain the following line:

Actual IP-DSU Service State ==> Peer Connectivity Established.

### **6.2.6 CHECK /VAR/OPT/DK/LOG/DKDAEMONLOG**

Enter the following command on the host computer:

```
# tail -17 /var/opt/dk/log/dkdaemonlog
```

This displays the log file created by *dkdaemon(1M)*. The output should look similar to the following report:

```
Dec 18 14:55:09 (8866) /opt/dk/sbin/dkdaemon : Started, Log Level = 5
```

```
Dec 18 14:55:09 (8867) acct_start: Accounting Disabled
```



**IP-CommKit Installation and Administration Guide  
for HP-UX – Issue 2 – Release 1.0.22**

```
Dec 18 14:55:09 (8867) /opt/dk/sbin/dkdaemon : Startup Complete
Dec 18 14:55:09 (8867) dkhsstart: Unit 0: 512 Chans, Ver 4, Rbuf 1024, NurpB 4
Dec 18 14:55:09 (8867) startstr: dkhs Unit 0 ACTIVE
Dec 18 14:55:09 (8867) startstr: dkhs Unit 1 Down, Retrying
Dec 18 14:55:09 (8867) startstr: dkhs Unit 2 Down, Retrying
Dec 18 14:55:09 (8867) startstr: dkhs Unit 3 Down, Retrying
Dec 18 14:55:09 (8867) startstr: dkhs Unit 4 Down, Retrying
Dec 18 14:55:09 (8867) startstr: dkhs Unit 5 Down, Retrying
Dec 18 14:55:09 (8867) startstr: dkhs Unit 6 Down, Retrying
Dec 18 14:55:09 (8867) startstr: dkhs Unit 7 Down, Retrying
Dec 18 14:55:09 (8867) startstr: dknp Unit 0 ACTIVE
Dec 18 14:55:09 (8867) startstr: dkxmx Unit 0 ACTIVE
Dec 18 14:55:09 (8867) LOG: (0, 0) dkxqt mux driver is active
Dec 18 14:55:11 (8867) SERVER: (0, 2) "dino" Started by UID 0
```

By default, *dkdaemon* tries to start all eight logical interfaces. Only one logical interface is used on the host computer where this log file was generated. This is **Unit 0**, and *dkdaemon* reports that it is **ACTIVE**. *dkdaemon* reports that the remaining logical interfaces are **Down**. On your host, you should check that all logical interfaces that you specified in the *dkiptab* are active.

If the messages that you see don't look similar to any of the examples above, consult the *dkdaemon* (1M) manual page. This describes all messages that are written to the log file.

Once *dkdaemon* starts, the host computer establishes communications with the BNS node controller. You can confirm this by running the following command on the BNS node console:



**IP-CommKit Installation and Administration Guide  
for HP-UX – Issue 2 – Release 1.0.22**

CC0> disp conn mod *mod\_address*

Here, *mod\_address* is the slot number where you installed the UTM. The output should look similar to the report below:

00-12-19 17:46:20 NODE=*node\_name*

M display connections mod *mod\_address*

MODULE: 19

-----

CH/PT	CU/TM	GROUP	PKT CNT	STATE	TO MOD	CH/PT	CU/TM	GROUP	PKT CNT
BOARD		(+ = PDD			BOARD				
CS/LCH		or PVC,			CS/LCH				
PT/LCH		# = RRC)			PT/LCH				
PT/DLCI					PT/DLCI				
1	****	295		<b>ACTIVE</b>					

Note that channel 1 is in the **ACTIVE** state.

### 6.2.7 CHECK /VAR/OPT/DK/DKSRVLOG

Enter the following command on the host computer

```
$ tail /var/opt/dk/log/dksrvlog
```



**IP-CommKit Installation and Administration Guide  
for HP-UX – Issue 2 – Release 1.0.22**

This displays the log file generated by *dkserver*(1M). The last few lines of the output should look similar to the following report:

```
Dec 18 14:55:11 (8893) [0.000] SERVER dino is INITING files=(/etc/opt/dk/srvtab  
/etc/opt/dk/dkuidtab) loglvl=6
```

```
Dec 18 14:55:11 (8893) [0.000] dkmgr : SERVER dino is ACTIVE and SERVING
```

The host file where this log file was generated is named *dino*, and it runs a single *dkserver* process. The last line of the log file indicates that *dkserver* is **ACTIVE and SERVING**. Some hosts run several *dkserver* processes. The last line should be repeated for each *dkserver* process.

You might see an error message similar to the one below in the log file:

```
Dec 19 17:00:59 (515) [0.000] ERROR dkmgr: Unable to create server server_name dk_errno  
= 3
```

The indicates that the address **server\_name** has not been entered on the BNS node, or that the address is not in service. Enter the following command on the BNS node to check the address:

```
CC0> ver addr all server_name
```

The report should be similar to the one below:



**IP-CommKit Installation and Administration Guide  
for HP-UX – Issue 2 – Release 1.0.22**

00-12-19 17:16:42 NODE=*node\_name*

M verify address all ***server\_name***

MNEMONIC ADDRESS: ***server\_name*** X.121 NANP ADDRESS:

LEVEL: local                   **SERVICE STATE: in**

PAD SUPPORT: no

DIRECTORY: none

SECURITY: none

GROUP: *group\_name*

If the report indicates that the address has not been entered, enter it using the instructions in the *BNS Node Configuration* section of this document. If the report shows that the address is out of service, restore the address with the following command:

```
CC0> res addr local server_name
```

When dkserver starts, it tells the BNS node that it is ready to accept incoming calls. You can confirm this by entering the follow command on the BNS node console:

```
CC0> disp conn mod mod_address
```



# IP-CommKit Installation and Administration Guide for HP-UX – Issue 2 – Release 1.0.22

The report should be similar to the one below:

```
00-12-19 17:46:20 NODE=node_name
```

```
M display connections mod mod_address
```

```
MODULE: 19
```

```
-----
```

CH/PT	CU/TM	GROUP	PKT CNT	STATE	TO MOD	CH/PT	CU/TM	GROUP	PKT CNT
BOARD			(+ = PDD		BOARD				
CS/LCH			or PVC,		CS/LCH				
PT/LCH			# = RRC)		PT/LCH				
PT/DLCI					PT/DLCI				
1	****	295	ACTIVE						
2	<i>group_name</i>	89	<b>SERVING</b>						

Note that channel 2 is in the **SERVING** state.

## 6.3 STOPPING AND STARTING

Some configuration changes require stopping and starting the IP-CommKit software to make the changes effective. Specifically, changes to `/etc/opt/dk/dkiptab` require stopping and starting. You can always do this by rebooting the host computer. However, this can be disruptive and time consuming. A more convenient method is to log in as root, then enter the follow commands:

```
# sh /sbin/init.d/dkitrc stop
```

```
# sh /sbin/init.d/dkitrc start
```



## **7 COMPATIBILITY**

This section of the *CommKit Host Interface for NCR PCI Computers Installation and Administration Guide* describes the differences between UNIX System V Release 3 (SVR3) and Release 4 (SVR4) versions. IP-CommKit for HP-UX was derived from the SRV4 version, so the information in this section also applies to IP-CommKit. However, it's only useful if you are porting a CommKit Host Interface application that ran under SRV3 to IP-CommKit.



## **8 MANUAL PAGES**

Most of the manual pages for the CommKit Host Interface are identical to those for IP-CommKit. The following man pages have been eliminated:

**ATDIAG**

**DKCFG**

**DKDIAG**

**DKMAP**

**DKREGISTER**

**DKUNLOCK**

**DKVfy**

**PCDIAG**

These pages described commands that were used for copy protection or fiber interface hardware configuration and diagnostics. These commands are not needed for IP-CommKit.

The following manual pages have been added or revised for IP-CommKit

**DKIPD**

**DKIPTAB**

**DKITRC**



## **9 END-USER LICENSE AGREEMENT FOR SOFTWARE**

This License Agreement ("License") is a legal contract between you and the manufacturer ("Manufacturer") of the software product(s) you acquired identified as ("SOFTWARE"). The SOFTWARE may include printed materials that accompany the SOFTWARE. Any software provided along with the SOFTWARE that is associated with a separate end-user license agreement is licensed to you under the terms of that license agreement. By installing, copying, downloading, accessing or otherwise using the SOFTWARE, you agree to be bound by the terms of this LICENSE. If you do not agree to the terms of this LICENSE, Manufacturer is unwilling to license the SOFTWARE to you. In such event, you may not use or copy the SOFTWARE, and you should promptly contact Manufacturer for instructions on return of the unused product(s) for a refund.

### **9.1 SOFTWARE LICENSE**

You may only install and use one copy of the SOFTWARE on one host computer (unless otherwise licensed by Manufacturer). The SOFTWARE may not be installed, accessed, displayed, run, shared or used concurrently on or from different computers, including a workstation, terminal or other digital electronic device ("Devices"). Notwithstanding the foregoing and except as otherwise provided below, any number of Devices may access or otherwise utilize the services of the SOFTWARE. You may not reverse engineer, decompile, or disassemble the SOFTWARE, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation. The SOFTWARE is licensed as a single product. Its component parts may not be separated for use on more than one host computer. You may not rent, lease or lend the SOFTWARE in any manner. You may permanently transfer all of your rights under this LICENSE provided you retain no copies, you transfer all of the SOFTWARE (including all component parts, the media and printed materials, any upgrades, this LICENSE and, if applicable, the Certificate(s) of Authenticity), and the recipient agrees to the terms of this LICENSE. If the SOFTWARE is an upgrade, any transfer must also include all prior versions of the SOFTWARE. Without prejudice to any other rights, Manufacturer may terminate this LICENSE if you fail to comply with the terms and conditions of this LICENSE. In such event, you must destroy all copies of the SOFTWARE and all of its component parts.

### **9.2 INTELLECTUAL PROPERTY RIGHTS**

The SOFTWARE is licensed, not sold to you. The SOFTWARE is protected by copyright laws and international copyright treaties, as well as other intellectual property laws and treaties. You may not copy the printed materials accompanying the SOFTWARE. All title and intellectual property rights in and to the content which may be accessed through use of the SOFTWARE is the property of the respective content owner and may be protected by applicable copyright or other intellectual property laws and treaties. This LICENSE grants you no rights to use such content. All rights not expressly granted under this LICENSE are reserved Manufacturer and its licensors (if any).



### **9.3 SOFTWARE SUPPORT**

SOFTWARE support is provided by Manufacturer, or its affiliates or subsidiaries separate from the host computer on which it may be installed. SOFTWARE support is limited to the warranty period stated below unless either a separate contract has been consummated between you and the manufacturer or the manufacturer has agreed in writing at the time of purchase by you of the software to an extension of the warranty. Should you have any questions concerning this LICENSE, or if you desire to contact Manufacturer for any other reason, please refer to the address provided in the documentation for the SOFTWARE.

### **9.4 EXPORT RESTRICTIONS**

You agree that you will not export or re-export the SOFTWARE to any country, person, or entity subject to U.S. export restrictions. You specifically agree not to export or re-export the SOFTWARE: (i) to any country to which the U.S. has embargoed or restricted the export of goods or services, which as of March 1998 include, but are not necessarily limited to Cuba, Iran, Iraq, Libya, North Korea, Sudan and Syria, or to any national of any such country, wherever located, who intends to transmit or transport the products back to such country; (ii) to any person or entity who you know or have reason to know will utilize the SOFTWARE or portion thereof in the design, development or production of nuclear, chemical or biological weapons; or (iii) to any person or entity who has been prohibited from participating in U.S. export transactions by any federal agency of the U.S. government.

### **9.5 LIMITED WARRANTY**

Manufacturer warrants that (a) the SOFTWARE will perform substantially in accordance with the accompanying written materials for a period of ninety (90) days from the date of shipment from Datatek Applications, Inc. Software support is limited to the hours of 9 AM to 5 PM ET Monday through Friday excluding Datatek-observed holidays. Other coverage and extended warranty may be purchased at additional cost. Any implied warranties on the SOFTWARE are limited to ninety (90) days. Some states/jurisdictions do not allow limitations on duration of an implied warranty, so the above limitation may not apply to you.

Manufacturer's and its suppliers' entire liability and your exclusive remedy shall be, at Manufacturer's option, either (a) return of the price paid, or (b) repair or replacement of the SOFTWARE that does not meet this Limited Warranty and which is returned to Manufacturer with a copy of your receipt. This Limited Warranty is void if failure of the SOFTWARE has resulted from accident, abuse, or misapplication. Any replacement SOFTWARE will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer.

### **9.6 NO OTHER WARRANTIES**

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, MANUFACTURER AND ITS SUPPLIERS DISCLAIM ALL OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT, WITH REGARD TO THE SOFTWARE AND THE ACCOMPANYING WRITTEN MATERIALS. THIS LIMITED



WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHERS, WHICH VARY FROM STATE/JURISDICTION TO STATE/JURISDICTION.

## **9.7 SPECIAL PROVISIONS**

The SOFTWARE and documentation are provided with RESTRICTED RIGHTS. Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Software clause at DFARS 252.227-7013 or subparagraphs (c)(1) and (2) of the Commercial Software-Restricted Rights at 48 CFR 52.227-19, as applicable. Manufacturer is Datatek Applications, Inc., 379 Campus Drive, Suite 100, Somerset, NJ 08873.

If you acquired the SOFTWARE in the United States of America, this Software License are governed by the laws of the State of New Jersey, excluding its choice of laws provisions. If you acquired the SOFTWARE outside the United States of America, local law may apply. This LICENSE constitutes the entire understanding and agreement between you and the Manufacturer in relation to the SOFTWARE and supersedes any and all prior or other communications, statements, documents, agreements or other information between the parties with respect to the subject matter hereof.

## **9.8 LIMITATION OF LIABILITY**

**To the maximum extent permitted by applicable law, in no event shall Manufacturer or its suppliers be liable for any damages whatsoever (including without limitation, special, incidental, consequential, or indirect damages for personal injury, loss of business profits, business interruption, loss of business information, or any other pecuniary loss) arising out of the use of or inability to use this product, even if Manufacturer has been advised of the possibility of such damages.** In any case, Manufacturer's and its suppliers' entire liability under any provision of this License shall be limited to the amount actually paid by you for the SOFTWARE. Because some states/jurisdictions do not allow the exclusion or limitation of liability for consequential or incidental damages, the above limitation may not apply to you.

©Copyright 2001, 2012 Datatek Applications, Inc.

All Rights Reserved

Printed in USA

